

MAKING REPAIRS TO DAMAGED MEMBRANE

Should the RGT membrane be damaged or punctured during application or due to installation of new roof equipment, etc., repairs should be made using RG-110 Flashing Compound and/or PF-1000 Polyester Fabric as follows:

1. Damaged areas need to be cut, cleaned and dried.
2. Apply Flashing Compound feathered out onto the existing RGT membrane.
3. If a new penetration area has been cut, embed PF-1000 Polyester Fabric into the Flashing Compound according to standard RGT specifications (see specification sheet PF-1000 and RG-110).
4. After the Flashing Compound has cured, apply the appropriate RGT Finish Coat for a uniform color.